

Instructions for Use



- 1 Remove measuring scoop from container (See Photo 1)
- 2 (Optional) Pour contents into larger bucket or container
- 3 Overfill measuring scoop with pigment (See Photo 2)
- 4 Using the palm of your hand, compact the dry pigment as much as possible (See Photo 3)
- 5 Add additional pigment to overfill the scoop and compact again
- 6 Compacted scoop of pigment is now ready for 1 batch or bag of cementitious material
- 7 Additional scoops (up to 4 total) may be added to achieve additional colors. When using more than one scoop per bag, it is recommended that you measure out pigment for each bag or batch before you begin mixing (See Photo 4)
- 8 A subsite sample is always recommended

Additives: DO NOT USE CALCIUM CHLORIDE Plasticizers, water reducers, non-chloride accelerators, and air entraining products that are designed for colored concrete may be used

Curing: DO NOT COVER, FOG OR WET CURE COLORED SURFACES

Warranty: PROFESSIONAL USE ONLY. Product is intended for licensed concrete contractors, that have the experience and training to use this product. End user is responsible for product aptness and assumes all risks and liability. Obligations of the manufacturer will be limited to refunding the purchase price of replacing the product if deemed defective.

Clean-up

h...} %Á š [E·X%)}(·} v š]]w [E · } [Á] šoz} o U · š š v ([E o [E P μ o š]} v · X
 ^ Z o (>] (/ v (] v] š v š Á Z } [E] P] v o U μ v š % [E š [E]} w š š] w % [E [E š μ [E X
 ^ %o] o E } š · W o · ^ } v (š š Z ~ š ^ · v [E] v () [E [E % [E] } š [E š } μ · X d Z] ·] v () [E u š] [E v < μ · š r [E v š š μ v š } u [E Á š i † ò ó í - ñ ò ó ó X

ORRVILLE
 133 North Kohler Road
 Orrville, Ohio 44667
 (330) 682-5678

CLEVELAND
 7941 Granger Road
 Cleveland, Ohio 44125
 (216) 573-0770

COLUMBUS
 723 Taylor Avenue
 Columbus, Ohio 43219
 (614) 253-3326

