



*PREPPING THE SURFACE FOR RE-SEAL

1. POWER WASH THE AREA WITH A 3,500 PSI POWER WASHER
 - » HOLD POWER WASHER IN AN UPRIGHT POSITION HAVING THE WAND AS CLOSE TO THE SURFACE AS YOU CAN WITHOUT DAMAGING THE SURFACE (BETWEEN 8-14 IN.)
2. USE A LEAF BLOWER TO BLOW OFF ALL STANDING WATER ON THE SURFACE & IN THE SAW CUTS
 - » DO THIS AS SOON AS POSSIBLE TO KEEP WATER FROM SOAKING INTO THE CONCRETE
3. LET THE AREA DRY FOR 24 HRS. BEFORE YOU RE-SEAL

