



Step #	Installation Step	Installation Methods	Products & Mix Ratios	Theoretical Coverage Rates
1	Mechanically Prepare Substrate Note: Minimum (CSP) concrete surface profile of CSP-3 or higher is required depending on substrate conditions & coating requirements.	a. Sandblasting or b. Shotblasting or c. Diamond grinding or d. Other similar and approved mechanical methods.	Miracote CQ Matrix Epoxy Broadcast Flooring Systems must be applied to a clean, sound, and mechanically prepared concrete substrate, as per ICRI's Technical Guide No.03732. <i>"Selecting and Specifying Concrete Surface Preparation.."</i> Concrete surface must be dry at the time of application.	N/A
2	Prime Substrate CQ Clear Epoxy	a. Dip and Roll b. Squeegee and backroll Note: Use 3/16" or 1/4" nap only	Blend CQ Clear Epoxy Mix Ratio A:B = 2:1 by Volume CQ Clear Epoxy Package Sizes: 3 Gal Kit or 15 Gal Kit	200-250 SF/Gal 6.4 to 8.0 mils WFT
3	Broadcast Coat CQ Clear Epoxy	a. Notched Squeegee and Backroll	Blend CQ Clear Epoxy Mix Ratio A:B = 2:1 by Volume	160 SF/Gal 10 mils WFT
4	Broadcast Miracote Colored Quartz Aggregate to Excess	a. Hand broadcast or b. Mechanically broadcast	Miracote Colored Quartz Aggregate 15 Standard Solid Colors 18 Pre-blended Decorative Colors One (1) Bag = 50 LBS	1 LB Per SF Note: Recovery of excess aggregate can typically range between 60-70%.
5	Remove Excess Colored Quartz Aggregate	After epoxy broadcast system has sufficiently cured to be resistant to damage, carefully remove excess aggregate by broom and vacuum. Re-use of recovered aggregate is allowable provided it is clean and free of contaminants.		
6	Lock Coat CQ Clear Epoxy	a. Squeegee and Backroll	Blend CQ Clear Epoxy Mix Ratio A:B = 2:1 by Volume	65 - 120 SF/Gal Note: Epoxy seal/lock coat coverage rates above are dependent on the desired texture of the finished surface and appropriate installation method.
7	Optional - Lightly Sand & Tack Wipe	Lightly sand or tack wipe lock coat if cure time exceeds 24 hours @ 75F before application of the Top Coat.		
Choose any of the Miracote sealers or topcoats for best results depending on location, service, use and exposure. Refer to the Product Technical Data Sheets and Installation Guides for Miracote CQ Clear Epoxy, Mirathane WB, Mirathane APU 100, or Glazetop				
8	Optional Addition of Synthetic Aggregate for Skid Resistance		Miracote Synthetic Skid Resistance Aggregate Add Maximum 4 Ounces/Gal to Any of the Above Finish Coats	4 fl oz

Note: Prior to starting the application of any Miracote Product or System be sure to read the Installation Guideline Manual. Appendices, Product Data Sheets, MSDS and other pertinent documents published by Crossfield Product Corp. for information, including but not limited to, Precautions, Limitations, Disclaimers and Warranties.

Pay special attention to substrate moisture content, physical condition of the substrate, method(s) of surface preparation, surface restoration, detailing of cracks, joints, transitions and terminations, and any applicable specifications. Review carefully for unknown site conditions or defects.

The theoretical coverage rates stated in the Installation Guides are for estimating purposes only. Factors, such as, allowance for material waste, unusual or abnormal substrate conditions and other unforeseen job site conditions that may affect actual product yields are the responsibility of the installer.